



PETLIBRO.COM

PETLIBRO

AIR Smart Feeder

©PETLIBRO All Rights Reserved

Model: PLAF108

Manufacturer: Shenzhen Libro Technology Co., Ltd.

Address: 12/F, Tower B, GALAXY WORLD, Yabao Road,
Longgang District, Shenzhen, China

Made in China

PLAF108-V0004

FCC ID: 2A3DE-PLAF108
CAN ICES-003 (B)/NMB-003(B)

IC: 28987-PLAF108




This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

PETLIBRO®

Model: PLAF108

USER MANUAL

AIR Smart Feeder



Please read this manual before using the product and keep it for future reference. Or open the PETLIBRO app and go to DEVICE SETTINGS > Instructions for the digital manual and instructional video.

CONTENTS

/ ENGLISH

01 — SAFETY INSTRUCTIONS

03 — WARRANTY

04 — NOTICE

06 — EXTERNAL POWER SUPPLY

07 — IN THE BOX

08 — PRODUCT OVERVIEW

11 — GETTING STARTED

19 — SPECIFICATIONS

/日本語

21 - 安全上の注意事項

22 - 保証

23 - 同梱物

24 - 製品概要

27 - はじめに

26 - 仕様

SAFETY INSTRUCTIONS

- Use the feeder in a dry place.
- Use the feeder on a level surface.
- Dispose of all packaging materials properly. Some items may be packed in plastic bags; these bags could cause suffocation.
- Keep them away from children and pets.
- Do not use the feeder with pets that are not able to reach the food bowl or with any physical disability.
- Do not immerse the base part in water at any time as it may damage electronic components.
- Do not use the feeder outdoors. Check its operation frequently to be sure it is operating properly.
- Do not disassemble the feeder other than as instructed in this user manual.
- Only use accessories recommended or sold by the manufacturer. The use of accessories not recommended or sold by the manufacturer may cause an unsafe condition.
- Do not modify the feeder.
- Examine the feeder after installation. Do not plug in if there is water on the power cable or plug.
- To avoid tripping, always position the power cable out of the way of foot traffic.
- Do not install or store the feeder where it will be exposed to weather or temperatures below 0°C (32°F).
- Do not use the feeder without adding pet food first.
- Power off the feeder when it's not in use.
- This appliance can be used by children aged from 8

years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- The appliance is only to be used with the power supply unit provided with the appliance.
- If the cord set is damaged, it must be replaced by a special cord set available from the manufacturer or its service agent.

WARRANTY

- 24-month warranty
- For guidance on product use, please contact our customer service team via email:
support@petlibro.com.

NOTICE

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC's and IC's RF radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must be installed and operated to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. Installers must ensure that 20cm separation distance will be maintained between the device (excluding its handset) and users.

WEEE Disposal and Recycling Information

All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.


EXTERNAL POWER SUPPLY

only to be used with the power supply unit provided with the appliance.

Model list:

US: TPA-46B050100UU
TPA-418G050100CU01
EU: TPA-147K050100VU01
TPA-67B050100VU01
TPA-46050100VU
TPA-418K050100VU01
UK: TPA-38A050100BU01
TPA-418B050100BU01
JP: TPA-95A050100UU01
TPA-98B050100PU01
TPA-418G050100PU01
AU: TPA-418K050100SU01
TPA-147C050100SU01

IN THE BOX



Automatic Pet Feeder

X1



Stainless Steel Bowl

X1



Bowl Tray

X1



Quick Start Guide

X1



User Manual

X1



Power Adapter


X1



Power Cable

X1

PRODUCT OVERVIEW



1. Lid Release Button

2. Lid

3. Food Tank

4. Tank Base

5. Rotor

6. Indicator


7. Food Tank Lock

8. Food Outlet

9. Stainless Steel Bowl

10. Bowl Tray

Indicator Status



11. Power Cable Slot
12. USB-C Power Port
13. Reset Button

14. Power Switch
15. Non-slip Rubber Pad

Buttons


Buttons	Operation
 ON OFF	Toggle the power switch to "ON" to turn on the power, and toggle to "OFF" to turn off
 Reset	Press and hold for three seconds, and the feeder will automatically reset

Indicator Status	Device Status
Off	The feeder is powered off or has a dead battery
Flashing white once every second	When the feeder is powered on and waiting for Wi-Fi connection
Flashing white once every half a second	Network configuration & OTA update
White on	Wi-Fi is connected
	The battery is fully charged
Breathing white once every second	Charging and Wi-Fi is connected
	Charging while the feeder is powered off
Breathing red once every second	Food levels are low
	The rotor is stuck
Red on	Low battery
Flashing red and white once every half a second	Wi-Fi connection failure


GETTING STARTED

Installation


1. Remove the food tank cover and take out the accessories.



2. Connect the power cable. (Use the feeder wirelessly after fully charging its battery.)




3. Toggle the power switch to "ON" to turn on the feeder.




Add pet food

1. Press the lid release button and remove the lid.




4. Install the stainless steel bowl and bowl tray.



2. Add dry pet food to the food tank.

3. Replace the lid and press the lid release button.




App control

1. Scan the QR code or search in your device's app store to download and install the PETLIBRO app.




2. Follow the instructions to configure the network.



Power off


Toggle the power switch to "OFF."




Bottom view

Disassemble for cleaning


1. Pull the food tank locks outwards.




2. Lift the food tank cover.



3. Hold the tank base, turn the rotor clockwise, and lift the rotor.



4. Clean and air-dry the rotor, food bowl, and the food tank cover.



Note



Scan the QR code above to watch the video for product installation and cleaning.

Notes

- Power off the device before cleaning.
- Clean the food bowl with tap water.
- Do not clean the feeder in a dishwasher. Only the stainless steel bowl is dishwasher safe.
- Use a soft damp cloth to clean the feeder base. Do not wash any part with electronic components.

SPECIFICATIONS

Model	PLAF108
Input	AC 100–240V 50/60Hz
Food tank capacity	2L
Battery capacity	5200mAh
Dimensions	310 × 265 × 180mm / 12.2 × 10.4 × 7.1in
Weight	1.3kg / 2.86lb

安全上の注意事項


- ・給餌器は乾燥した場所で使用してください。
- ・給餌器は水平な場所で使用してください。
- ・すべての梱包材は適切に廃棄してください。一部の品目はビニール袋に詰められている場合があります。これらの袋は窒息を引き起こす可能性があります。
- ・子供やペットには近づけないようにしてください。
- ・フードボウルに口が届かないペットや身体に障害のあるペットとは給餌器を使用しないでください。
- ・電子部品が損傷することがありますので、ベース部分を水に浸さないでください。
- ・給餌器は屋外で使用しないでください。動作を頻繁にチェックして、正しく動作していることを確認してください。
- ・このユーザーマニュアルに記載されている以外の方法で給餌器を分解しないでください。
- ・メーカーが推奨または販売しているアクセサリのみを使用してください。メーカーが推奨または販売していないアクセサリを使用すると、危険な状態になることがあります。
- ・給餌器は改造しないでください。
- ・設置後に給餌器を検査してください。電源ケーブルやプラグに水がついている場合は、プラグを差し込まないでください。
- ・つまずきを避けるために、電源ケーブルは常に人の往来の邪魔にならない位置に置いてください。
- ・給餌器は、0°C(32°F)以下の天候や温度にさらされる場所に設置または保管しないでください。

- ・給餌器は、ペットフードが入っていない状態で使用しないでください。
- ・給餌器を使用していないときは、給餌器の電源をオフにしてください。

保証

- ・24ヶ月保証
- ・製品の使用に関するガイドラインについては、カスタマーサービスチームまで電子メールsupport@petlibro.comでお問い合わせください。

同梱物



自動ペット給餌器

X1



ステンレス製ボウル

X1



ボウルトレイ

X1



クイックスタートガイド

X1



ユーザーマニュアル

X1



電源アダプター


X1



電源ケーブル

X1

製品概要



1.蓋着脱ボタン

2.蓋

3.フードタンク

4.タンクベース部

5.ローター

6.表示


7.フードタンクロック

8.餌出口

9.ステンレス製ボウル

10.ボウルトレイ

表示の状態



11. 電源ケーブルスロット 14. 電源スイッチ
 12. USB-C電源ポート 15. すべり止めゴムパッド
 13. リセットボタン

表示の状態	デバイスの状態
消灯	給餌器が電源オフであるか、バッテリー切れである
1秒に1回白色に点滅	1秒に1回白色に点滅 給餌器の電源がオンで、Wi-Fi接続を待っている
0.5秒に1回白色に点滅	ネットワーク設定とOTAアップデート中
白色点灯	Wi-Fiが接続されている バッテリーが完全に充電されている
1秒に1回白色に点滅	充電中でWi-Fiが接続されている 給餌器の電源がオフで充電中である
1秒に1回赤色に点滅	餌貯蔵量が不足している ローターが餌詰まりしている
赤色点灯	電池残量不足
半秒に1回、赤と白で点滅	Wi-Fi接続が失敗した


ボタン

ボタン	操作
	電源を入れるには電源スイッチを「オン」に切り替え、電源を切るには「オフ」に切り替えます。
	3秒間押すと、給餌器が自動的にリセットされます。


はじめに

設置


1. フードタンクのカバーを外し、付属品を取り出してください。



2. 電源ケーブルを接続してください。(バッテリーを完全に充電した後、ワイヤレスで給餌器を使用してください。)




3. 電源スイッチを「オン」に切り替えて、給餌器の電源を入れてください。




ペットフードを入れる


1. 蓋着脱ボタンを押して、蓋を取り外してください。



4. ステンレス製ボウルとボウルトレイを取り付けてください。



2. ドライペットフードをフードタンクに入れてください。
3. 蓋を元に戻し、蓋着脱ボタンを押してください。




アプリ制御

1. QR コードをスキャンするか、デバイスの App Store で検索して、PETLIBRO アプリをダウンロードしてインストールしてください。




電源オフ

電源スイッチを「オフ」に切り替えてください。




2. 指示に従ってネットワークを設定してください。




清掃のために分解する


1. フードタンクロックを外側に引き出してください。




2. フードタンクカバーを持ち上げてください



3. タンクベース部を持ってローターを時計回りに回し、ローターを持ち上げてください。



4. ローター、フードボウル、そしてフードタンクのカバーをきれいにして風に乾かしてください。



仕様



上記のQRコードを読み取って、本機の設置および清掃に関するビデオをご覧ください。

注

- ・清掃する前にデバイスの電源を切ってください。
- ・フードボウルを水道水で洗浄してください。
- ・食器洗い機で給餌器を洗浄しないでください。食器洗い機に対応しているのは、ステンレス製ボウルのみです。
- ・柔らかい湿った布を使用して、給餌器ベース部を清掃してください。電子部品が付いた部分は洗わないでください。

モデル	PLAF108
入力電源	AC 100～240V 50/60Hz
フードタンク容量	2L
バッテリー容量	5200mAh
寸法	310 × 265 × 180mm / 12.2 × 10.4 × 7.1インチ
重量	1.3kg / 2.86ポンド