

**PETLIBRO®**

品牌：PETLIBRO  
公司：深圳乐木骆科技有限公司

设计师：Zoe  
日期：2024.05.09

物料名称：  
Petlibro-WF007-2.5L-说明书US\_JP-V0001

成型尺寸：高130mm X 宽80mm

材质：纯白书纸80g

印刷工艺：  
四色印刷，骑马钉

备注：



PETLIBRO.COM

## PETLIBRO

GLACIER Ultrafiltration Fountain

**Model:** PLWF007

**©PETLIBRO All Rights Reserved**

**Manufacturer:** Shenzhen Libro Technology Co., Ltd.

**Address:** 12/F, Tower B, GALAXY WORLD, Yabao Road,  
Longgang District, Shenzhen, China

**JP Importer:** 株式会社成洋

**Made in China**

PLWF007-V0001




CAN ICES-003 (B)/NMB-003(B)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# PETLIBRO®

## USER MANUAL

GLACIER Ultrafiltration Fountain



\*Please read this manual before using the product and keep it for future reference.

# Contents


/ English

In The Box	01
Product Overview	02
Getting Started	06
Specifications	07
Safety Instructions	08
Warranty	09
Notice	09


/ 日本語

同梱物	11
製品概要	12
はじめに	16
仕様	17
安全上の注意事項	18
保証	19


## In the Box



1 × Automatic  
Pet Water Fountain




1 × Power Adapter



1 × Power Cable




1 × User Manual




1 × Cleaning Brush



## Product Overview




- 1. Water Tank
- 2. Water Tray
- 3. Water Outlet
- 4. Water Level Indicator
- 5. Filter Life Indicator
- 6. Power Button
- 7. Filter Life Reset Button
- 8. Pyroelectric Sensor
- 9. Ultrafiltration Filter




## Button




Button	Operation Status
 Power	Press and hold for three seconds to power on/off
 Filter Life Reset	After replacing the filter, press and hold for six seconds to reset the filter life






## Water Level Indicator



Indicator Status	Device Status
 White on	Sufficient water level
 Red on	Insufficient water level
 Off	The water fountain is powered off

## Filter Life Indicator



Indicator Status	Device Status
 Three blue lights on	The filter life is about 40–60 days
 Two blue lights on	The filter life is about 20–40 days
 One blue light on	The filter life is about 7–20 days
 One red light on	The filter life is less than 7 days
 Three lights off	The water fountain is powered off

## Getting Started




Scan the QR code above to watch the video for product installation and cleaning.

### Notes:

- Replace the filter every **two months** as indicated by the filter life indicator.
- Clean the water tank at least once every **seven** days.


## Power on

Plug the fountain into a wall outlet using the power adapter and power cable.



## Power off

Unplug the cable from the outlet or press and hold the power button for three seconds.



## Specifications

<b>Model</b>	<b>PLWF007</b>
Power Adapter	Input: AC 100-240V 50/60Hz Output: DC 5V 1A
Water Tank Capacity	2.5L
Water Tank Material	SUS304 stainless steel
Dimensions	265 × 220 × 167mm 10.43 × 8.66 × 6.57in
Weight	1.75kg / 3.86lb

## Safety Instructions

- Use the fountain in a dry place.
- Use the fountain on a level surface.
- Dispose of **all** packaging materials properly. Some items may be packed in plastic bags; these bags could cause suffocation. Keep them away from children and pets.
- Do not use the water fountain with pets that are not able to reach the water tray or with any physical disability.
- Do not immerse the water fountain (except the tank) in water at any time as it may damage electronic components.
- Do not use the fountain outdoors. Check its operation frequently to be sure it is operating properly.
- Do not disassemble the fountain other than as instructed in this user manual.
- **Only** use accessories recommended or sold by the manufacturer. The use of accessories not recommended or sold by the manufacturer may cause an unsafe condition.
- Do not modify the fountain.
- Examine the fountain after installation. Do not plug in if there is water on the power cable or plug.
- To avoid tripping, **always** position the power cable out of the way of foot traffic.
- Do not **install** or store the fountain where it **will** be exposed to weather or temperatures below 0°C (32°F).
- Do not use the fountain without adding water first.
- Power off the fountain when it's not in use.

## Warranty

- 24-month warranty
- For guidance on product use, please contact our customer service team via email: [support@petlibro.com](mailto:support@petlibro.com).

## Notice

### FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
  - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to

try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

### Radio frequency exposure statement


To maintain compliance with the FCC's RF Exposure Guidelines, this equipment should be installed and operated with a minimum distance of 20cm from your body.




## 同梱物



自動  
ペット給水器×1 個




電源アダプター×1 個



電源ケーブル×1 個




ユーザーマニュアル×1 個




クリーニングブラシ×1 個



## 製品概要




- |              |                   |
|--------------|-------------------|
| 1. ウォータタンク   | 6. 電源ボタン          |
| 2. ウォータトレイ   | 7. フィルター寿命リセットボタン |
| 3. 吐水口       | 8. 焦電センサ          |
| 4. 水位計       | 9. 限外濾過フィルター      |
| 5. フィルター寿命表示 |                   |




## ボタン




ボタン	動作状態
 電源	電源をオン/オフするには、3秒間押し続けます。
 フィルター寿命リセット	フィルターを交換した後、6秒間押し続けると、フィルタの寿命がリセットされます。






## 水位計



表示の状態	デバイスの状態
 白色点灯	水位は十分です
 赤色点灯	水位が不十分です
 消灯	給水器の電源がオフになっています

## フィルター寿命表示



表示の状態	デバイスの状態
 3つの青色ライトが点灯	フィルター寿命は40～60日です
 2つの青色ライトが点灯	フィルター寿命は20～40日です
 1つの青色ライトが点灯	フィルター寿命は7～20日です
 1つの赤色ライトが点灯	フィルターの寿命は7日未満です
 3つのライトが消灯	給水器の電源がオフになっています

## はじめに




上記の QR コードを読み取って、本機の設置および清掃に関するビデオをご覧ください。

### 注：

- ・2ヶ月ごとに、フィルター寿命インジケータの指示に従ってフィルターを交換してください。
- ・ウォータータンクは 7 日に 1 回以上清掃してください。


## 電源オン

電源アダプタと電源ケーブルを使用して、給水器を壁のコンセントに差し込みます。



## 電源オフ

ケーブルをコンセントから抜くか、電源ボタンを 3 秒間押したままにします。



## 仕様

モデル	PLWF007
電源アダプター	入力: AC100~240V、50/60Hz 出力: DC 5V 1A
ウォータータンク容量	2.5L
ウォータータンク材質	SUS304ステンレス鋼
寸法	265 x 220 x 167mm 10.43 x 8.66 x 6.57インチ
重量	1.75kg/3.86ポンド

## 安全上の注意事項

- 給水器は乾燥した場所で使用してください。
- 給水器は水平面上で使用してください。
- すべての梱包材は適切に廃棄してください。一部の品目はビニール袋に詰められている場合があります。これらの袋は窒息を引き起こす可能性があります。子供やペットには近づけないようにしてください。
- ウォータートレイに口が届かないペットや身体に障害のあるペットには給水器を使用しないでください。
- 電子部品を損傷することがありますので、給水器（タンクを除く）を水に浸さないでください。
- 給水器は屋外で使用しないでください。動作を頻繁にチェックして、正しく動作していることを確認してください。
- このユーザーマニュアルに記載されている以外の方法で給水器を分解しないでください。
- メーカーが推奨または販売しているアクセサリのみを使用してください。メーカーが推奨または販売していないアクセサリを使用すると、危険な状態になることがあります。
- 給水器は改造しないでください。
- 設置後に給水器を検査してください。電源ケーブルやプラグに水がついている場合は、プラグを差し込まないでください。
- つまづきを避けるために、電源ケーブルは常に人の往来の邪魔にならない位置に置いてください。
- 噴水は、0°C (32°F) 未満の天候や温度にさらされない場所に設置または保管してください。
- 給水器は、最初に水を加えてから使用してください。
- 使用していないときは、電源を切ってください。

## 保証

- 24 ヶ月保証
- 製品の使用に関するガイダンスについては、カスタマーサービスチームに電子メール: **support@petlibro.com** でお問い合わせください。